



























montážní návod / installation instruction
BLS800/BLS900




PARTS LIST








 1 X4	 2 ST4*30 X8	 3 X6	 4 X2	 5 X2	 6 X2
 7 X2	 8 ST4*13 X6	 9 16mm X2	 10 12mm X2	 11 X2	 12 X1
 13 X2	 14 ST4*40 X6	 15 ST4*10 X4	 16 X4	 17 X6	 18 X8
 19 X2	 20 X4	 21 ST4*8 X8	 22 Φ3 X1		

TOOLS






INSTALLATION





STEP 1










STEP 2










STEP 3







STEP 4









STEP 5






STEP 6







STEP 7






STEP 8



STEP 9



STEP 10



STEP 11

