


























# Montážní návod / Assembly instruction

WI070 / WI071, WI080 / WI081, WI090 / WI091  
WI100 / WI101, WI110 / WI111



	B	
	Min(mm)	Max(mm)
700x1900	675	690
800x1900	775	790
900x1900	875	890
1000x1900	975	990
1100x1900	1075	1090

**A****B****C****D**