





7


Montážní návod Assembly instruction

HLF707Y
HLF808Y
HLF909Y





UBC s.r.o.
Mělnická 87, 250 65 Bořanovice, Pakoměřice, Czech Republic
IČ: 27146987 | DIČ: CZ27146987

Tel.: +420 283 090 760 | Fax: +420 283 090 761
E-mail: info@aqualine.cz | Internet: www.aqualine.cz





A		X2	I		X2	Q		X2
B		X2	J		X2	R		X8
C		X4	K		X4	S		X8
D		X2	L		X4	T		X1
E		X2	M		X6	S		X2
F		X2	N		X14			
G		X2	O		X8			
H		X4	P		X10			

G		X2	T		X1
H		X2	L		X4
K		X4			








D		X2	H		X2
E		X2	P	 M4*10	X2
F		X2	Q	 M4*8	X2
I		X2			




5

A		X2
M		X6
N	 M4*30	X6




2

B		X2	O		X4
C		X4	P	 M4*10	X4
S	 M4*	X2	N	 M4*30	X8
R		X8	S	 M4*10	X8



3

O		X4
P	 M4*10	X4



4