







Montážní návod / Assembly instruction



















WI070/WI071,WI080/WI081,WI090/WI091
WI100/WI101,WI110/WI111,WI120/WI121



① x1	② x1	③ x5
④ x5	⑤ x1	⑥ x1



	B	
	Min(mm)	Max(mm)
700x1900	675	690
800x1900	775	790
900x1900	875	890
1000x1900	975	990
1100x1900	1075	1090
1200x1900	1175	1190

A**B****C****D**