


Instalační manuál


(EN) Installation manual
 (DE) Installationsanleitung
 (SK) Inštalčný manuál
 (PL) Instrukcja montażu
 (HU) Telepítési útmutató




PRX.101.851



A




B



C

A varianta/solution/Variante/variant/wariant/változat


1




2

A


B




3




4



5




6




B

varianta/solution/Variante/variant/wariant/változat


1




2




3




4



5




6




C

varianta/solution/Variante/variant/wariant/változat


1




2




3



4



5



6

