


# montážní návod / installation instruction











ES3A70/ES3A70B/  
ES3A80/ES3A80B/  
ES3A90/ES3A90B/  
ES3A10/ES3A10B/  
ES3A12/ES3A12B

ES3B30/ES3B30B/  
ES3B40/ES3B40B/  
ES3B50/ES3B50B/  
ES3B60/ES3B60B


**polysan**

Polysan s.r.o.  
Nesměřice 52  
285 22 Zruč nad Sázavou  
www.polysan.cz




ES3A-L/R	ES3B-L/R	A	B	C
ES3A70	ES3B-30	685-700	985-1000	314
ES3A80	ES3B-30	785-800	1085-1100	314
ES3A90	ES3B-30	885-900	1185-1200	314
ES3A10	ES3B-30	985-1000	1285-1300	314
ES3A12	ES3B-30	1185-1200	1485-1500	314
ES3A70	ES3B-40	685-700	1085-1100	414
ES3A80	ES3B-40	785-800	1185-1200	414
ES3A90	ES3B-40	885-900	1285-1300	414
ES3A10	ES3B-40	985-1000	1385-1400	414
ES3A12	ES3B-40	1185-1200	1585-1600	414
ES3A70	ES3B-50	685-700	1185-1200	514
ES3A80	ES3B-50	785-800	1285-1300	514
ES3A90	ES3B-50	885-900	1385-1400	514
ES3A10	ES3B-50	985-1000	1485-1500	514
ES3A12	ES3B-50	1185-1200	1685-1700	514
ES3A70	ES3B-60	685-700	1285-1300	614
ES3A80	ES3B-60	785-800	1385-1400	614
ES3A90	ES3B-60	885-900	1485-1500	614
ES3A10	ES3B-60	985-1000	1585-1600	614
ES3A12	ES3B-50	1185-1200	1785-1800	614

A



C1


+  
ES7010  
ES7025



OR


C2

+  
ES7810  
ES7825




B

+  
ES8010  
ES8025



D



E

